

Firmware Release Note


Model : CLP-680ND, DW		Date :	August 27, 2019
Version	Category	Change Description	
V4.00.01.55 (18-Mar, 2014)	Fix Defect	Tray1 Pickup Roller error is displayed	
V4.00.01.61 (7-Aug, 2014)	Fix Defect	1. Change of Supplies Information Report 2. Photo Quality Improvement	
V4.00.02.20 (14-Nov, 2014)	Fix Defect	Fix the C5-1710 Error issue	
		Fix the wireless network issue	
V4.00.02.25 (12-Mar, 2015)	Fix Defect	Junk characters are printed when PDF print is given through Direct Print.	
		Not display Hebrew download font.	
		Remove unused Network Port such as TCP 22 port.	
		"Control Panel Lock" feature is not working when we import a Clone File.	
		[Google Cloud Print] Print & deregistration doesn't work properly	
		A1-4111(Actuator Motor Failure) Error	
	Add Func.	Google Cloud Print 2.0 feature	
		Samsung Cloud Print feature	
		Mopria Print feature	
V4.00.02.26 (18-Mar, 2015)	Fix Defect	Fix Reboot error in case print with Empty Toner	
V4.xx.02.28 (7-Sep,2015)	Add Func.	Apply PCL5, PCL6, PS	
		Apply the QR Code on Configuration Report	
		Apply to Toner Status and Easy setup of Samsung Cloud Print	
	Fix Defect	Improve the paper jam on MP Tray	
		Fix LDAP authentication issues	
		Fix Toner Low and Toner replacement alert setting issues	
V4.xx.02.32 (9-Sep, 2016)	Add Func.	Apply to PrinterOn Agent(Cloud Print).	
		Added "Network Connection Status" to Network Configuration Report	
	Fix Defect	Improved an image registration problem by the Auto Color Registration failure.	
		Improved A1-1210 Error	
		Secure SMTP value is not retaining after reboot.	
V4.xx.02.33 (27-Aug, 2019)	Fix Defect	Fix the printer rebooting issue.	

※ Note

- Please do not turn off the printer and your computer until firmware update finishes.
- If you are using USB connection, disconnect all other USB printers from the PC.
- The firmware update you are about to install has been tested for compatibility with Samsung toner cartridge products ONLY.
Installing The upgrade may cause a non-Samsung toner cartridge to malfunction.
- Do not run your printer during the firmware update.(Do not have any print job)

How to update the firmware using a USB cable.

1. Make sure that the machine is connected to the PC with a USB cable.
2. Check the current firmware version of your printer.
 - If the firmware version is V4.xx.01.48 and more lower,
Execute a patch file(CLP680DW_UpgradeJig.exe)
And then patch rom will be download on the
Please wait until green LED is ON.(About 2~3
 - If the firmware version is V4.xx.01.49 and more higher, Go to next step.
3. Drag the firmware file(*.hd) and Drop down it on usblst2.exe.
And then, firmware update will be started automatically.



How to update the firmware for a network connected printer.

1. Check the current firmware version of your printer.
 - If the firmware version is V4.xx.01.48 and more lower,
Execute a patch file(CLP680DW_UpgradeJig.exe)
And then patch rom will be download on the
Please wait until green LED is ON.(About 2~3
 - If the firmware version is V4.xx.01.49 and more higher, Go to next step.
2. Open Internet Explorer and enter the IP address of your printer.
3. Go to the SyncThruWeb Service (SWS) main home page.
Login as Admin in SyncThruWeb Service.
NOTE: Login using the Administrator ID and Password established during initial machine setup.
4. Click [Maintenance] on the top menu.
And then click [Firmware Upgrade] or Application Management > Application
5. Click Add button
6. Click [Browse].
Choose installation file by browsing file system. And click OK button
7. The firmware update will start.
Once the f/w update is complete, the machine power-off and power-on automatically.