

Firmware Release Note

SAMSUNG

Model : SL-C460W, SL-C467W	Date :	May 30, 2016
-----------------------------------	---------------	---------------------

Version	Category	Change Description
V3.00.02.06 (7-Apr, 2014)	Fix Defect	Fixed the problem that Android 4.3 (JB) mobile device can't connect when wifi direct connection was max.
		Fixed NFC connection problem.
V3.00.02.07 (15-Apr, 2014)	Fix Defect	Improvement of Color to Mono Printing Problem
		Fixed Google Cloud Print issue. ("chunked" data control)
		Changed the target temperautre for improvement of Naonodust
V3.00.02.13 (10-Oct, 2014)	Fix Defect	Try to printing JPEG files via AirPrint on iOS8, printer is rebooting
V3.00.02.16 (22-Dec, 2014)	Fix Defect	Fix USB PC printing blocking problem
V3.00.02.21 (4-Jan, 2016)	New Func.	Apply to Samsung Cloud Print
		Apply new font in PCL5, PCL6
	Fix Defect	[Google Cloud Print] Print & deregistration does not work properly
		Improve Fax transimistion on VoIP line(for Israel 'HOT' line)
		Fix Print quality(pullation) issue

※ Note

- Please do not turn off the printer and your computer until firmware update finishes.
 - If you are using USB connection, disconnect all other USB printers from the PC.
 - The firmware update you are about to install has been tested for compatibility with Samsung toner cartridge products ONLY.
- Installing The upgrade may cause a non-Samsung toner cartridge to malfunction.
- Do not run your printer during the firmware update.(Do not have any print job)

How to update the firmware

1. Make sure that the machine is connected to the PC with a USB cable
2. Check the currently f/w version of your printer.

If the f/w version is V3.xx.01.xx, execute a upgrade patch file as below.

2-1) Execute C46xW_Upgrade_Patch.exe

And then patch rom will be download on the machine

2-2) Please wait until green LED is ON.(About 2 minute)


* Reference

- ① Red LED Blinking for about 30 sec
- ② Green LED ON for 30 sec
- ③ Red LED Blinking for 60 sec
- ④ Green LED ON


Go on the next step

If the f/w version is V3.xx.02.xx, go on No. 3

3. Drag 'SWUPGRADE_ON.prn' and drop down it on usblist.exe.



4. Drag a f/w file 'C460W_V3.00.02.21.hd' and Drop down it on usblist2.exe



5. The firmware update will start.

Once the firmware update is complete, the machine will be rebooted automatically.